

TEEL HOPPER COVER TYPES



TYPE - A COVER CENTER HINGE OPENS FRONT & BACK

- ** BASIC MODEL WITH SEGMENTED HINGES (NO GASKET) **
- DRAIN CHANNEL ** ** WATER TIGHT MODEL WITH CONTINOUS HINGE AND 1/4" GASKET & CENTER
- ** NOT RECOMENDED FOR MODEL 680 HOPPERS AND ABOVE **




- ** BASIC MODEL WITH SEGMENTED HINGES (NO GASKET) **

 ** WATER TIGHT MODEL WITH CONTINOUS HINGE AND 1/4" GASKET **

 ** AVAILABLE ON ALL HOPPER MODELS **


NOTE: GASKET MATERIAL IS 1/4" x I" NEOPRENE



TYPE - B COVER CENTER HINGE OPENS IN FRONT HALF ONLY

- ** BASIC MODEL WITH SEGMENTED HINGES (NO GASKET) **

 ** WATER TIGHT MODEL WITH CONTINOUS HINGE AND I/4" GASKET & CENTER
- ** RECOMENDED FOR MODEL 680 HOPPERS AND ABOVE **



TYPE - D COVER CENTER HINGE OPENS IN FRONT HALF ONLY

- ** BASIC MODEL WITH SEGMENTED HINGES (NO GASKET) **

 ** WATER TIGHT MODEL WITH CONTINOUS HINGE AND I/4" GASKET
- ** RECOMENDED FOR MODEL 680 HOPPERS AND ABOVE **